

Collins Manufacturing Company
Assembly Instructions

Hydraulic Styling Chair or All Purpose Chair

- **Remove chair top, tubular steel footrest, and hydraulic base from carton. Using 1/2” wrench, remove plywood piece from top of hydraulic base.**
- **Locate bolts and washers in small plastic bag stapled to the bottom of the chair. Align the four holes in the ends of the footrest with the four holes located toward the front of the seat cushion. Using 7/16” wrench, bolt the footrest to the seat cushion with bolts & washers provided. Be sure to use lock washers & securely tighten the bolts.**
- **Place the chair top assembly on the hydraulic base, aligning the “keyway” or slot in the seat casting with the “key” near the top of the hydraulic base. Sit in the chair to “lock” the chair top assembly firmly onto the hydraulic base.**

Spring-Back or Lever-Control Shampoo Chair

- **Remove chair top, die cast base, and column assembly from carton.**
- **Locate bolts and washers in small plastic bag stapled to the bottom of the chair. Align the four holes in the seat plate with the four holes in the bottom of the seat cushion, insuring that the “straight” side of the seat plate is facing the back mechanism of the chair. Using 7/16” wrench, bolt the seat plate & column assembly to the seat cushion with the bolts & washers provided.**
- **Place the tapered end of the column into the hole in the center of the die cast aluminum base. Sit in the chair to “lock” the chair top assembly firmly into the base.**

Recycle or properly dispose of all packaging materials.

If you have any questions, call 800-292-6450 Tollfree