## N104-2 Nail Table with the Ventilation

## Installation to the wall

- 1. Make a 2" Hole on back of the table at any desirable location. 2. Pull Flex pipe (2" OD) through the hole to connect.

