
To assemble the Amati station follow this procedure.

- 1) Place the cabinet assembly as desired against a framed wall. Use the provided 3" wood screws to secure the cabinet to the wall behind. You may conceal the screw heads by placing them behind the drawers. Use the illustrated procedure for removing and reinstalling the drawers.
- 4) Assemble the mirror frame by passing the supplied screws into the pre-drilled/tapped holes in the metal. You may wish to cut the side pieces of the mirror frame down to accommodate your ceiling type.
- 5) Place the mirror frame on top of the lower base and against the wall. The reccomended spacing is 3" from the side of the metal to the side of the tall base cabinet. Use the supplied wood screws to attach the mirror frame panel to the wall.
- 6) With the cabinets and mirror frame installed, locate the supplied mirror clips and attach to pre drilled holes in the mirror frame. Install mirror by first seating into the bottom clips then lifting the upper clips to seat the top of the mirror.



Pull the drawer fully open so levers are visible.

Push "down" on the right lever(shown), and "up" on the left lever.

Holding levers in place, pull drawer toward you.

To Reinsert Drawer

Bring ball retainer fully forward and <u>carefully</u> reinsert drawer member slide into the cabinet member slide, guiding the drawer member raceway between the ball bearings. Completely close drawer.

Open and close drawer to ensure the slide is fully engaged into the ball bearing track.

This item includes a six outlet power strip with a 4' cord. The outlet strip is rated at 15 amps. The electrician is responsible for providing and mounting an outlet inside the cabinet for the power strip to plug into. The electrician is also responsible for cutting an appropriate entry point for getting power into the cabinet.

All electrical work is to be

All electrical work is to be performed by a licensed electrical contractor and to be performed in accordance with all applicable national, state, and local codes.

Quantity -

Finish Schedule -940-48-1

Face Color -Top Color -


Toe Color - Sliver Legs Reveal / Accent Color -Hardware - Amati Pulls Interior - Black Melamine Other (Specify) -

General Notes:

- 1. All counter tops are to be made removable wherever possible.
- 2. Items must be broken into managable sections For Shipping. Mark For Ease Of Reassembly.
- 3. Install Shipping Cleats Wherever Possible To Prevent Shipping Damage.
- 4. Purchased items Must Be Trial Fit Before Shipping.



Wire Path



Finish Schedule -937-48-1

Face Color Top Color Toe Color - Sliver Legs
Reveal / Accent Color Hardware - Amati Pulls
Interior - Black Melamine

Other (Specify) -

General Notes:

- 1. All counter tops are to be made removable wherever possible.
- 2. Items must be broken into managable sections For Shipping. Mark For Ease Of Reassembly.
- 3. Install Shipping Cleats Wherever Possible To Prevent Shipping Damage.
- 4. Purchased items Must Be Trial Fit Before Shipping.

