

Installing Your Custom Framed Mirror



Tools Required

- Hammer
- Drill with 1/4" and 3/16" drill bits
- Phillips head screwdriver
- Level

Step One

Inspect frame and mirror for any damages or manufacturer defects.

Step Two


Locate all hardware:

- 1 hangrail on the top of the frame
- 2 security brackets on the bottom of the frame (1 bracket on smaller frames)
- 4 L brackets, one on each corner

Hanging hardware will be packaged separately.

It should include:

- 1 hangrail
- 12 screws with wall anchors
- 2 T-Bolts with wall anchors
- 1 security wrench (1 wrench per order)



Step Three

For best results, always install frame into one or more wall studs. When a stud is not available, use provided wall anchors.

Install hangrail(s) at the desired height, with the screw holes facing downward. Use wall anchors if necessary.

Step Four

Hang the frame onto the wall by interlocking the hangrails into each other.

Step Five

With the frame hanging on the wall and level, apply slight pressure to the bottom of the frame where the security brackets are installed. **DO NOT PRESS ON MIRROR.** This slight pressure will make an indentation on the wall of where the security bracket opening rests on the wall.

Remove the frame and set aside.

Step Six

Install the wall anchors in the middle of the security bracket indentation on the wall.

Step Seven

Insert the T-Bolt into the wall anchor, leaving approximately 3/8" off the wall and in a horizontal position. There should be no thread visible.

Step Eight

Place frame back on to the wall, allowing the T-Bolt to enter the security bracket. Using the security wrench provided, reach behind the frame and locate the T-Bolt. Turn the bolt 90-degrees, locking the frame onto the wall.

